

NBRT PARCEL 3  
SEQUENCE OF EVENTS

1. Develop Health and Safety Plan (see HASP minimum requirements)
2. Mark Parcel 3 boundaries
3. Remove fence
4. Determine method of new fencing installation (all excavated material must be spread on site)
5. Install erosion and sediment control measures
6. Install tree protection markers around nine designated trees
7. Cut and clear brush and all other trees
8. Chip and stack small brush and stack large wood adjacent to Parcel 3
9. Install 2'high drop inlet and 18" drainage pipe (30' long) and outlet apron
10. Spread excavated material on Parcel 3
11. Cover site with orange demarcation geotextile (geotextile provided by Town of Bath)
12. Install tree wells and place geoweb (geoweb provided by Town of Bath) around designated trees
13. Fill geoweb with clean #57 gravel
14. Haul and spread entire site with earthfill obtained from designated location to obtain a 23" cap
15. Install fence on boundary between Parcel 3 and Parcel 2
16. Apply soil amendments, seed, and mulch
17. Supply wage information to town representative.